



Dell XPS 17 L702X Battery Replacement

A guide to replace battery for the Dell XPS 17 L702X

Written By: Shin Sul



Step 1 — Battery



- Flip over the laptop with the bottom battery compartment facing up.

Step 2



- Slide the tab below the battery leftwards and hold.

Step 3



- While holding the tab, lift the battery out of its compartment.
- Release the tab after removing the battery.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-08 07:56:24 AM.